

QUICK START GUIDE



ActisenseCloud

Get connected to your vessel's data in minutes. Follow the steps below to create your account, link your device, and log in.



No Actisense account yet? You'll need to register before starting. Visit actisense.com/actisense-hub and create a free account first.

SETUP STEPS

PART 1 - ACCESS THE WEBAPP & CONNECT TO THE INTERNET

- 1 Connect to your Actisense device's Wi-Fi access point**
On your device, connect to your Actisense device's Wi-Fi network. Then open a browser window and go to **<http://192.168.4.1>** to access the webApp.
- 2 Navigate to Settings/Wi-Fi Client**
In the webApp, go to **Settings > Wi-Fi Client**. The username is "admin" and the unique password is in the box with your Actisense device.
- 3 Run a scan & connect to a Wi-Fi network**
Tap **Scan** to discover available Wi-Fi networks. Select a network from the scan results that has internet access and enter its password. The device must be online to reach ActisenseCloud.

PART 2 - ENABLE & CLAIM CLOUD

- 4 Navigate to Settings/Cloud & enable Cloud functionality.**
Back in the webApp, go to **Settings > Cloud**. Toggle on the Cloud feature. This allows your device to begin communicating with the ActisenseCloud service.
- 5 Claim your device**
Click the **Claim** button or scan the QR code displayed. This links your device to your Actisense account.
- 6 Configure your device in the Cloud webApp**
Once claimed, go to **Device > Config** to configure your device.